

INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS

1455 Kleppe Lane ◆Sparks, NV 89431-6467 ◆(775) 359-4712 ◆Fax (775) 359-7424 E-mail: haws@hawsco.com ◆ website: www.hawsco.com

No. 2076851(13)

Model 1431 Drinking Fountain

NOTE TO INSTALLER: Please leave this information with the Maintenance Department.

LIMITED WARRANTY

HAWS warrants that this specific product is guaranteed against defective material or poor workmanship for a period of one year from date of shipment. HAWS liability under this warranty shall be discharged by furnishing without charge F.O.B. HAWS Factory any goods, or part thereof, which shall appear to the Company upon inspection to be of defective material or not of first class workmanship, provided that claim is made in writing to Haws within a reasonable period after receipt of the product. Where claims for defects are made, the defective part or parts shall be delivered to the Company, prepaid, for inspection. HAWS will not be liable for the cost of repairs, alterations or replacements, or for any expense connected therewith made by the owner or his agents, except upon written authority from HAWS, Sparks, Nevada. HAWS will not be liable for any damages caused by defective materials or poor workmanship, except for replacements, as provided above. Buyer agrees that HAWS shall not be liable for general, special, or consequential damages claimed to arise under the contract of sale. The drinking fountain manufactured by HAWS is warranted to function if installation and maintenance instructions provided are adhered to. The units also must be used for the purpose for which they were intended.

NO OTHER WARRANTIES EXPRESSED OR IMPLIED ARE AUTHORIZED, PROVIDED OR GIVEN BY HAWS.

SHOULD YOU EXPERIENCE DIFFICULTY WITH THE INSTALLATION OF THIS MODEL PLEASE CALL:

TECHNICAL SUPPORT: 1-800-766-5612

FOR CUSTOMER SERVICE: 1-888-640-4297

RECOMMENDED TOOLS: Hack saw, pipe joint sealant, screwdriver, level, 12" adjustable wrench, 10" pipe wrench, 5/64" hex key wrench, 9/16", 1/2", 7/16" socket wrench or open end wrench.

LOCATION OF UNIT: The Model 1431 Drinking Fountain is a wheelchair accessible drinking water facility. The height dimensions shown, meet current ADA requirements. When installing this unit, local, state or federal codes should be adhered to. If height other than shown is required, then dimensions must be adjusted accordingly.

SUPPLY LINE: The minimum recommended line size is 1/2" IPS with 30-90 psi (2-6 ATM) flowing pressure. Where sediment or mineral content is a problem, an inlet filter is recommended.

PLUMBING CONNECTIONS: Inlet is 3/8" O.D. tubing fitting. Waste trap outlet is 1-1/2" IPS.

MAINTENANCE: Periodically clean the strainer. Refer to 5874SS Valve Manual for more information.

INSTALLATION PROCEDURE

GENERAL NOTES:

- For all plastic push-in type fitting connections, only connect NSF-61 copper or plastic tubing. Stainless steel or glass tubing is not recommended. The following assembly instructions must be followed to ensure a watertight connection:
 - a. Cut tubing square and clean.
 - b. Mark from end of tube the length of insertion (See table below).
 - c. Push tube into the fitting until it bottoms out.
 - d. To remove, depress collet and pull tubing out.

Tube Sizes	O.D. Tolerance	Insertion Depth
1/4"	±.005"	11/16"
3/8"	±.005"	3/4"
1/2"	±.005"	7/8"

Refer to Installation Drawing for mounting height. For steps below, refer to exploded view.

- **STEP 1:** Remove nut and washers from bubbler heads, set aside. Install bubbler head through receptor. Install respectively, rubber washer, fiber washer, then nut onto bubbler shank. Securely tighten nut.
- STEP 2: Remove push button assembly from 5874SS valves with spanner wrench provided. Be sure to also remove (chrome plated) ring nut and (chrome-plated) washer from valves. At this point, carefully follow installation instructions shown on page 5 of 5 of 5874SS Valve/Push Button Operation and Maintenance Manual under heading: "INSTALLATION INSTRUCTIONS FOR 5874SS W/PBA7"

INSTALLATION PROCEDURE

- **STEP 3:** Make tubing connections from bubbler to the outlet side of control valve. Follow instructions for tubing preparation and insertion depths from Step 3.
- **STEP 4:** Place strainer into receptor (using putty), secure in place using a fiber washer and lock nut.
- STEP 5: Mount fountain with appropriate hardware as shown on Installation Drawing.
- **STEP 6:** Flush supply line to clear debris. Connect to a 1/2" NPT supply line and tighten.
- **STEP 7:** Make certain that fountain is level and well secured to wall. Connect waste trap to a 1-1/2" waste pipe (to be supplied by customer).
- STEP 8: Completely open the screwdriver stop (not supplied) and check for leaks.
- STEP 9: Adjust valves for desired flow height. See 5874SS Valve Manual (supplied).
- **STEP 10:** Attach bottom plate to fountain using #10-24 hardware provided.

	TROUBLESHOOTING				
	PROBLEM	REPAIR CHECKLIST			
1.	Insufficient bubbler flow.	1a.	Check that inlet screwdriver stop valve is in wide-open position.		
		b.	Verify minimum 30 psi flowing supply pressure.		
		C.	Clean strainer. See 5874SS Valve Manual.		
		d.	Adjust valve to increase flow. Use front adjust screw or see 5874SS Valve Manual.		

For more information about Haws products, see our website: www.hawsco.com


© 2012 Haws[®] Corporation – All Rights Reserved HAWS[®] and other trademarks used in these materials are the exclusive property of Haws Corporation.


11/12

PARTS BREAKDOWN

NOTES:

- T FOR TUBING ROUTING AND LENGTHS SEE PAGE 2 OF INSTALLATION DRAWING.
- CONNECT WHITE "POLYPROPYLENE" TUBING ON PRESSURE SIDE (INLET) OF VALVE.
- 3 CONNECT CLEAR "POLYETHYLENE" TUBING ON FREE FLOW SIDE (VALVE TO BUBBLER HEAD) ONLY.
- 4 REFER TO 5874SS/VRK5874 OPERATION AND MAINTENANCE MANUAL FOR INSTALLATION INSTRUCTIONS.
- 5 MUST APPLY 1 DOT OF LOCTITE 222MS THREADLOCKER ON FEMALE THREADS OF PUSH BUTTON. SEE 5874SS OPERATION AND MAINTENANCE MANUAL (PAGE 5 OF 5) FOR PROPER APPLICATION PROCEDURE.





THIS DOCUMENT IS TRUE AND CORRECT AT TIME OF PUBLICATION, CONTINUED PRODUCT IMPROVEMENTS MAKE SPECIFICATIONS AND MEASUREMENTS SUBJECT TO CHANGE WITHOUT NOTICE. Ġ 4. ©2012 Haws Corporation - All Rights Reserved. HAWS® and other trademarks used in these materials are the exclusive property of Haws Corporation. CONNECT CLEAR "POLYETHYLENE" TUBING ON FREE FLOW SIDE (VALVE TO BUBBLER HEAD) CONNECT WHITE "POLYPROPYLENE" TUBING ON PRESSURE SIDE (INLET) OF VALVE. WHITE POLYPRO TUBING VALVE OUTLET **ELBOW FITTING CLEAR POLY TUBING** TEE FITTING (3-1/2") Ė WHITE POLYPRO TUBING **CLEAR POLY TUBING** W SCALE: 1:10 DRAWING TYPE MODEL(S) **ELBOW FITTING** VALVE OUTLET 1431 1455 KLEPPE LANE
SPARKS, NEVADA 89431
(775) 359-4712 FAX (755) 359-7424
E-MAIL: HAWIS@HAWISCO.COM
WEBSITE: WWW.HAWISCO.COM
PART NUMBER
0002076851.D