


- NOTES:
1. INSERT STRAINER BODY AS SHOWN, APPLY PLUM GUM TO INDICATED SURFACE AS REQUIRED
 2. INSERT FIBER, TWO RUBBER AND METAL WASHERS AS SHOWN, TIGHTEN HEX NUT TO MAKE A SECURE JOINT
 3. INSERT PLASTIC BUSHING IN END OF TAILPIECE AS SHOWN, SLIDE TAILPIECE NUT IN POSITION AS SHOWN AND TIGHTEN

		INFO FAX : 1-888-FAX-HANS (1-888-339-4297) 1465 Kinnear Ln. Stony Brook, NY 11790 Phone: 775-359-4712 Fax: 775-359-7424 Haws Ag Building 3 CH-3401 Burgdorf Switzerland Haws Mfg Pte Ltd 74 Sungai Kadut, Loop Singapore 729531 e-mail: haws@hansco.com website: www.hansco.com	
MODEL NO. 1100 DATE 8/2/83	TITLE: STRAINER MODEL: 12530	DRAWN BY: [blank] CHECKED BY: [blank]	DESIGNED BY: [blank] DATE: [blank]