

NOTES: (CONTINUED FROM SHEET 1)

- 4. LIGHT REPLACEMENT INSTRUCTIONS:
 - 1) REMOVE GUARD AND GLOBE:
 FIRST LOOSEN SET SCREW (LOCATED ON GUARD
 WHERE SHOWN). NEXT, ROTATE GUARD COUNTER
 CLOCKWISE UNTIL GUARD IS FREE. FINALLY ROTATE
 GLOBE COUNTER CLOCKWISE UNTIL GLOBE IS FREE
 AND LAMP IS EXPOSED.
 - 2) REPLACE LAMP WITH RECOMMENDED 130 VOLT, 60 WATT, RED. P/N 0003225505

WARNING - EXPLOSION HAZARD - SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS 1, DIVISION 2.

3) REPLACE GUARD AND GLOBE:
ROTATE GLOBE CLOCKWISE ONTO THREADS UNTIL
SEALED AGAINST GASKET. NEXT, ROTATE GUARD
CLOCKWISE ONTO THREADS UNTIL TIGHT. FINALLY
TIGHTEN SET SCREW.

